

THANK YOU FOR CHOOSING GREENE BROTHERS DESIGNS

You'll notice on one of the jam nuts it will have notches or a small groove on one end of the center link. That is the left hand thread side.

Start with that side and attach it to the trans side first.

Now attach the other end to the front mounting point.

Now you can adjust the center to move the ends apart to fine adjust your shifter to your liking. After you find where you like your shifter you'll need to tighten the jam nuts.

Extreme care must be taken at this point. With a rag and a pair of pliers hold the center link (**Carbon Fiber Only**) while tightening the jam nuts or a paper towel and a 9/16 wrench. Remember the rear jam nut is left hand thread.

Be sure to use blue loctite on the mounting Fasteners only.